

REVO FORWARD PIVOT SYNCRO

Ratchet Back Height Adjustment

Simply lift back to desired position and back locks automatically. To release and reset back position, lift back completely to top stop and return to bottom stop and then move up to the new position.

Infinite Position Tilt Lock

To lock chair in position, push paddle down. To allow free rocking movement, pull paddle up.

Tension Knob

Turn clockwise to increase rocking tension, turn counter-clockwise to decrease tension.

Pneumatic Height Adjustment

To lower, lift paddle while seated. To raise, lift paddle with your weight off seat.

