

RATCHET BACK TRI-ACTION

Ratchet Back Height Adjustment

Simply lift back to desired position and back locks automatically. To release and reset back position, lift back completely to top stop and return to bottom stop and then move up to the new position.

Back Angle Adjustment

While seated, pull paddle up, when desired angle found push paddle down to lock. Back will free float in the paddle up position.

Infinite Seat Angle Adjustment with 6 degree Forward Tilt

To change seat angle, pull paddle up while seated, push paddle down to lock when desired angle is achieved. Seat can free float.

Pneumatic Height Adjustment

To lower, lift paddle while seated. To raise, lift paddle with your weight off seat.

