

## SEAT SLIDER

### Seat Slider

While seated, pull lever, push seat to desired depth and release lever to lock. Locks in 5 positions over 2 1/2 inches.

