

CONTROL OPTIONS

CONTROL 01
Swivel task

2" adjustment

CONTROL 03
Tri-Action

18"±2"

7°±1°
0°±1°

CONTROL 04
Multi-function

18"±2"

14°±1°
-3°±1°

CONTROL 05
Ratchet Back, Multi-Function

17"±2°

14°±1°
-3°±1°

CONTROL 06
Balance-Syncro

19"±2°

10°±1°
-7°±1°

CONTROL 07
Swivel Tilter

12"±2°

18°±1°
2°±1°

CONTROL 08
Knee Tilt, Ratchet Back, Multi-Function w/ built-in seat slider

15"±2°

17°±2°
-3°±2°

CONTROL 14
Forward Pivot Syncro w/ built-in seat slider

19"±2°

13°±1°
1°±1°

CONTROL NS
Ratchet back, Enhanced Task

12"±2°

18°±1°
2°±1°

A TENSION KNOB
Turn clockwise to increase tension, turn counter-clockwise to decrease tension.

B SEAT SLIDER
Pull lever, push seat to desired depth and release lever to lock. Locks in 5 positions over 2".

C BACK REST POSITION ADJUSTMENT
Loosen hand wheel (do not remove), and slide back to desired position, then re-tighten hand wheel.

D BACK ANGLE ADJUSTMENT
While seated, pull paddle up, when desired angle found, push paddle down to lock. Back Free floats in the paddle up position.

F PNEUMATIC HEIGHT ADJUSTMENT
To lower, lift paddle while seated. To raise, lift paddle with your weight off seat.

G SYNCHRO TILT
Turn the knob clockwise to lock backrest in position. To unlock, turn the knob counter-clockwise and lean back on the chair to release the anti-kickback mechanism.

H BACK HEIGHT ADJUSTMENT
Turn knob counter-clockwise to loosen, lift or lower chair back to desired position and re-tighten. Critical lumbar curve positioning.

CONTROL OPTIONS

I INFINITE SEAT ANGLE ADJUST WITH 3 DEGREE FORWARD TILT

To change seat angle, pull paddle up while seated, push paddle down to lock when desired angle is achieved. Seat can rock.

J INFINITE POSITION TILT LOCK

To lock chair in position, push paddle down. To allow free rocking movement, pull paddle up.

K RATCHET BACK HEIGHT ADJUSTMENT

Simply lift back to desired position and back locks automatically. To release and reset back position, lift back completely, then allow back to fall to bottom reset position.

L PNEUMATIC ADJUSTMENT/ TILT ROCK LOCK

Adjust to raise or lower seat (See F). The lever pushes in towards control to lock in the neutral position. Pull lever out to rock free.

M INFINITE TILT/ LOCK SCREW

Turn screw paddle to adjust seat tilt. Screw paddle system eliminates tilt slippage.

