

FOOT RING ASSEMBLY INSTRUCTIONS

Thanks for purchasing your new RFM Seating chair. Here is information on how to assemble your chair the best possible way. Visit our website at

www.rfmseating.com under our support tab for a pdf print out of this brochure.

PARTS

- 1. FOOTRING20 (1)
- 2. FOOTRINGHVY (1)
- 3. HRDWRE0092 (1)
- STEP 1. Place FOOTRINGHVY sleeve over the cylinder with screw (HRDWRE0092) toward the bottom.
- STEP 2. Slide the FOOTRINGHVY up the cylinder 4 inches above the bottom of the cylinder. Lightly tighten HRDWRE0092 with a #2 phillips screwdriver. (Not provided)
- STEP 3. Place the FOOTRING20 over the top of the cylinder and loosely tighten the two knobs of the FOOTRING20. One into hole and one against the FOOTRINGHVY.
- **STEP 4**. Place the cylinder into the base. Insert the cylinder into the cylinder receiver on the bottom of the control.
- **STEP 5**. To seat the cylinder in the control and base, sit on chair. After cylinder is seated, loosen HRDWRE0092 allowing FOOTRINGHVY to rest on base.
- **STEP 6**. Tighten HRDWRE0092. Adjust FOOTRING20 to desired height with 2 knobs.

